

## HOW TO INLAY WITH CRUSHED STONE

---

*One of the MOST often asked questions we get is : "How do I inlay crushed stone?"*

---

**WELL, IT'S REALLY SIMPLE, AND ONCE YOU'VE DONE IT, YOU'LL FIND IT HARD TO STOP!**

**FIRST, FIGURE OUT WHAT SIZE CRUSH YOU'LL WANT TO USE BASED ON THE VOID YOU WANT TO FILL (THE SMALLER THE VOID - THE SMALLER THE CRUSH). IN A SMALL DISPOSABLE CUP, MIX TOGETHER A CLEAR 2-PART EPOXY. ADD THE CRUSHED STONE TO THE EPOXY AND MIX TOGETHER UNTIL YOU GET A PASTE CONSISTENCY. THE AMOUNT OF WORKING TIME YOU HAVE WILL BE DEPENDENT OF THE EPOXY YOU CHOSE.**

**USE A TOOTHPICK OR POPSICLE STICK TO PRESS THE MIXTURE INTO YOUR VOIDS. MAKE SURE YOU COMPLETELY FILL THE VOID. A LITTLE OVERFLOW IS NOT A BAD THING AS IT WILL GET TURNED AND/OR SANDED FLUSH WITH THE SURFACE.**

**ALLOW THE EPOXY TO CURE FOLLOWING MANUFACTURER'S DIRECTIONS, THEN TURN/SAND UNTIL SMOOTH AND FLUSH WITH THE SURFACE OF YOUR PIECE. ONCE THE SANDING IS COMPLETE, YOU CAN FINISH YOUR PROJECT AS YOU NORMALLY WOULD.**

**FOR VERY SMALL VOIDS, YOU CAN USE CA GLUE IN PLACE OF THE EPOXY. FILL THE VOID WITH THE CA GLUE, THEN PRESS THE CRUSHED STONE INTO THE VOID. TOP OFF WITH A LITTLE MORE CA GLUE. SAND AND FINISH ONCE THE GLUE IS COMPLETELY CURED.**

**WHEN SANDING, IF YOU EVER FIND PARTS OF THE VOIDS WERE NOT COMPLETELY FILLED, YOU CAN REPEAT THE ABOVE PROCEDURES UNTIL THE VOID IS COMPLETELY FILLED.**

**HAVE FUN!!! IF YOU HAVE ANY QUESTIONS, YOU CAN ALWAYS GIVE US A CALL... WE'LL BE HAPPY TO HELP.**